






Návod k sestavení a ovládání auta VOLVO XC90 s 2,4G dálkovým ovládáním, 12V,








Odpojte motory,



Auto podložte polystyrenovou kostkou,
(bez podložení hrozí poškození okna a kapoty auta !,







Převodovky nasad'te až na doraz ke karoserii,



Osu doporučujeme namazat vazelinou, (stačí i tuk nebo olej na vaření,) (není v příslušenství auta !,)









Všechny osy namažte vazelinou nebo olejem,

▲ Safety Information

/! WARNING: Prevent injuries and deaths. Di adult supervision required. safe riding areas. These areas must be... away from swimming pools and other bodies of water. Avoid drowning.

Riding Rules: Make sure you follow these rules for safe driving and riding:

Always sit on the seat.

Always wear shoes.

Only 1 rider at a time.

FOR OUTDOOR USE ONLY.

/! CAUTION: this package contains small parts. For adult assembly only.

⚠ Safety Information

/!! WARNING: Prevent injuries and deaths. Direct adult supervision required. Keep children within safe riding areas. These areas must be... away from swimming pools and other bodies of water to prevent drownings.

generally level to prevent tipovers.
away from steps and steep inclines, cars, roads and all

Riding Rules: Make sure your children know and follow rules for safe driving and riding:

Always sit on the seat.
Always wear shoes.

Only 1 rider at a time.

FOR OUTDOOR USE ONLY.

/!! CAUTION: this package contains small parts.
assembly only.





injuries and deaths. Keep children in areas must be and other bodies of water to tipovers, up inclines, cars, roads and alleys. Your children know and follow these riding:

ILY.
e contains small parts. For adult





...urries and deaths. Select
d. Keep children within
and other bodies of water to
tipovers.
ep inclines, cars, roads and alleys.
ure your children know and follow these
and riding:
at.
86.
a time.
DOOR USE ONLY.
ON: this package contains small parts. For adult
only.



OUTDOOR
USE ONLY
UTION:
this package
contains small
parts assembly
only.

OUTDOOR USE ONLY.
UTION: this package contains small parts assembly only.





Information

Prevent injuries and deaths. Direct supervision is required. Keep children within sight. These areas must be...


ing pools and other bodies of water to prevent tipovers.

steep inclines, cars, roads and alleys.


sure your children know and follow these rules and riding:

ONLY.

age contains small parts. For adult





Mosazné konektory musí být v zástrčce rovně !, uprostřed !, pokud jsou ohnuté ke straně plastu srovnejte je, (stačí prstem),







Mosazné konektory musí být v zástrčce rovně !, uprostřed !,
pokud jsou ohnuty ke straně plastu srovnejte je, (stačí prstem),





















V otvoru pro osu volantu nesmí být žádný zbytek plastu,
pokud bude vidět zbytek plastu po lisování odstraňte jej,
(stačí prostrčit nějaký kulatý předmět,)



Po zapojení konektorů kabelů volant stále držte !!,
(jinak hrozí vytržení kabelů !!,)



Zapojené kably a konektor srovnejte a zastrčte do otvoru nad řízením,













Nabíjení baterie,

Čas nabíjení 10 - 12 hod / max.15 hod !!,

Při nabíjení může být nabíječka i baterie teplá - toto je normální,

Nabíječka,

Zásuvka pro nabíjení,



Důležité upozornění !,

Pokud vozítko nepoužíváte, baterii nabíjejte 1x měsíčně cca 6 hodin!,

Nedodržením zničíte nebo zkrátíte životnost baterie!, baterii chraňte před mrazem!,

Při nabíjení může být nabíječka i baterie teplá - toto je normální,



Písmenka před stahováním folie předem zatlačte ke karosérii,
folii stahujte plynule, písmenka druhou rukou přidržujte,

A black Volvo XC90 SUV is shown from a front-three-quarter angle, viewed from the side. The hood of the car is propped open, revealing the engine compartment. The car's headlights are illuminated, and the license plate area displays "XC90".

Možnost otevření kapoty,



Zespoða výklopné madlo pro tažení Volva,



Po otočení klíče:
na polohu ON = auto zapnuto,
na polohu se symbolem světla = světla zapnuta,
otočením klíče zpět do základní polohy = auto vypnuto,

Pedál pro jízdu,



Návod pro ovládání bluetooth rádia
je přiložen v krabici,

Muzika,

Klakson,

Řazení pro jízdu na pedál,
D = vpřed,
P = parking,
R = zpět,

2,4G bluetooth dálkový ovladač,



NO.:LCS1502100455E

2.4G Fregency remote control

Instructions

•Car_Select is required for the first time (or replace the battery) :

Step 1. Installing the remote control batteries, and the speed indicators will flash three times

Step 2 Press the Car_Select key for about 2 seconds, the Car_Select lamp will flash. Power on the car immediately .

Step3 The Car_Select lamp will off if successful , else repeat step 2 .

• Operation:

1. Speed selection - LOW speed: Only one lamp flashing; MED speed- Two lamps flashing; HIGH speed- Three lamps flashing. Each owns slow start and stop

2. Press the STOP key will stop the car ; Other keys like it meant.

3. The remote control will power off after 15's without operating, any key will power on.




WARNING

**This remote must be
used by adult only**



Vložte 2 mikrotužkové baterie R3, AAA,
pozor na správnou polaritu + / - !!,

2,4G bluetooth dálkový ovladač,
návod pro sladění s autíčkem,



Sladění 2,4G ovladače s autíčkem:

Klíč zastrčte do autíčka - autíčko musí zůstat a být vypnuté,

Vložte do ovladače baterie,

Zmačkněte a držte tlačítko car select cca 2 vteřiny dokud se nerozbliká LED dioda vedle tlačítka,

Při tom zapněte klíč na On polohu v autíčku - autíčko se musí zapnout,

Nyní je ovladač sladěn s autíčkem, poté jej můžete ovládat dle popisu,

Po několika cca 20 vteřinách nečinnosti se ovladač sám vypne,

Při výměně baterií nebo nefunkčnosti ovládání opakujte celý tento postup,



Volvo XC90 řídí Adámek, věk 5,5 roků (drobnější postavy),

